


































































































**Press  to get to Command Level 2, then press the desired "Cmnd" key**

<b>Cmnd</b>	Function	Edit Keys	OK	Exit
	<b>CREATE or EDIT CHANNEL</b>	 TO  SELECT CHANNEL MEMORY TO EDIT THEN EDIT: SCAN LIST (L2-5), TEXT DESCRIPTION (L2-6) OPERATING MODE (L1-3), FREQUENCY (L1-7), & SQUELCH (L1-9)		
	COPY GUARD TO MAIN	COPY CHANNEL INFORMATION FROM GUARD TO MAIN (default disabled)		
	<b>LOCK KEYPAD</b>	PRESS & HOLD  TO UNLOCK KEYPAD		
	n/u			
	EDIT SCAN LISTS	   STEP UP/DOWN THROUGH AVAILABLE SCAN LISTS  TOGGLE ENABLE/DISABLE FOR SCAN (BAR OVER DIGIT = DISABLED)		
	<b>EDIT CHANNEL TEXT</b>	 STEP THROUGH THE FOUR CHARACTER GROUPS ( <b>AZ, az, 09, and BLANK!</b> )   SCROLL UP & DOWN THROUGH CHARACTERS IN SELECTED GROUP   MOVE CURSOR LEFT & RIGHT		
	CREATE SHADOW	 TO  SELECT CHANNEL MEMORY TO EDIT THEN EDIT: TEXT (L2-6), MODE (L1-4), SQUELCH (L1-9)		
	COPY MAIN TO GUARD	COPY CHANNEL INFORMATION FROM MAIN TO GUARD (default disabled)		
	TOGGLE ENCRYPTION	TOGGLE ENCRYPTION ON/OFF (ONLY FOR MEMORIES WITH KEY ASSIGNED)		
	GO TO NEXT LEVEL	GO TO THE NEXT HIGHER COMMAND LEVEL		
	SET HOME CHANNEL	SET 'HOME' CHANNEL INTO MEMORY (FOR MAIN RADIO ONLY).		
	GO TO PREVIOUS LEVEL	GO TO THE PREVIOUS COMMAND LEVEL		

**Press  +  to get to Command Level 3, then the desired "Cmnd" key**

<b>Cmnd</b>	Function	Edit Keys	OK	Exit
	SET BOOT CHANNEL	   STEP UP/DOWN THROUGH BOOT MEMORY OPTIONS		
	ASSIGN KEY BY KEYTAG	  PICK MEMORY,   PICK KEY,   PICK DECRYPT OPTION		
	<b>SET P25 MODE</b>	   TOGGLE P25 <b>HEX/DECIMAL</b> EDIT MODE (For TGID & NAC CODES) (\$F56/3926)		
	DISPLAY FIRMWARE REV.	   STEP THROUGH MAIN & BOOT FIRMWARE VERSIONS		
	SET SCAN PARAMETERS	   SELECT REVERT MODE THEN  TO  SET TIMERS (REPLY, MONITOR, DELAY)		
	SET PTT TIMER	   STEP UP/DOWN THROUGH TIMER VALUES (30, 60, 90 SEC)		
	<b>SET SIDETONE AUDIO</b>	 TO  SET SIDETONE LEVEL (00 TO 85) ( <b>TDFM-136=52, TDFM-136A=68</b> )		
	PC COMMUNICATION	MUST BE CONNECTED TO A PC OPERATING TDP-136 SOFTWARE		
	<b>SHOW TONES/CODES</b>	   TOGGLE Rx/Tx SQUELCH PARAMETER DISPLAY ( <b>CHECK TONES</b> )		
	GO TO NEXT LEVEL	GO TO THE NEXT HIGHER COMMAND LEVEL ( <b>L4 PASSWORD PROTECTED</b> )		
	n/u			
	GO TO PREVIOUS LEVEL	GO TO THE PREVIOUS COMMAND LEVEL		

**NOTES:**

- The channel being edited is determined by the position of the front panel switches MN/GD and G1/G2.
- Current command level is shown at 4<sup>th</sup> character on bottom row (between GD2 and text).
- **Levels 2 & 3 time out. The radio will return to Level 1 if a "Cmnd" key is not entered within 5 seconds.**
- Download this Quick Reference Guide at [www.nifc.gov/resources/NIICD/niicd-documents](http://www.nifc.gov/resources/NIICD/niicd-documents)